

Presionar 2 seg el botón trasero



LED FLASHES x3



Presionar botón de destino



LED FLASHES x1



Pulsar emisor ORIGINAL hasta que el mando TERRA MAST haga 5 destellos o 3 destellos.

CORRECTO

LED FLASHES x5



ERROR

LED FLASHES x3

